

INSTALLATION INSTRUCTIONS WR400, WR600 & WS600 SUPPORT BRACKET ASSEMBLIES



Precision Architectural Lighting

4830 Timber Creek Drive Houston, Texas 77017
Tel (713) 946-4343 Fax (713) 946-4441 www.pal-lighting.com

CAUTION

- * BE CERTAIN THAT POWER TO FIELD WIRING HAS BEEN TURNED OFF PRIOR TO INSTALLATION.
- * CONNECTIONS TO FIELD WIRES AND GROUNDING OF FIXTURES MUST BE DONE IN ACCORDANCE WITH APPLICABLE LOCAL AND NATIONAL CODES.
- * WALL, CEILING OR JUNCTION BOX MUST BE STRUCTURALLY CAPABLE OF SUPPORTING WEIGHT OF FIXTURE AT SUSPENSION POINTS. DO NOT SUPPORT MORE THAN 50 LBS FROM JUNCTION BOX PER N.E.C.— SUSPENSION POINTS MAY BE SUBJECT TO ADDITIONAL LOADS DURING INSTALLATION AND SERVICE.
- * INSTALLATION MUST BE PERFORMED BY QUALIFIED PERSONNEL
- * BE CERTAIN THAT SUPPLY VOLTAGE IS THE SAME AS THAT MARKED ON BALLASTS AND TRANSFORMERS.

1. DETERMINE SPACING OF SUPPORT BRACKETS AND INCOMING FEED WIRE LOCATION. (FEED MAY OCCUR AT ANY SUPPORT BRACKET LOCATION).
2. MOUNT SUPPORT BRACKET SECURELY AT APPROPRIATE LOCATIONS (FASTENERS NOT PROVIDED). INCOMING FEED WIRES SHOULD BE ROUTED THROUGH THE HOLLOW NIPPLE AT FEED POINT. PRESS CANOPY FIRMLY ONTO THE SUPPORT BRACKET UNTIL IT IS FULLY SEATED AGAINST WALL OR CEILING.
3. REMOVE DIFFUSERS & REFLECTORS FROM FIXTURE AND POSITION FIXTURE ON SUPPORT BRACKETS SUCH THAT THE HOLLOW THREADED NIPPLES ARE PASSING THROUGH THE PRE-DRILLED HOLES IN THE FIXTURE HOUSING. INSTALL WASHER (IF REQUIRED) & LOCK NUT ON NIPPLE WITHIN FIXTURE HOUSING AND TIGHTEN LOCK NUT SECURELY.
4. MAKE WIRE CONNECTIONS WITHIN FIXTURE HOUSING (WIRE AND CONNECTORS MUST BE RATED FOR 90°C MINIMUM) AND REPLACE REFLECTORS, LAMPS AND DIFFUSERS (IF REQUIRED).

